

CAD605 Instruction



Smart Button

- Press and **hold** the **B** button on the remote
 - Press and release the Green 'Smart button'
 - Release the B Code button
- The transmitter has been programmed into the opener

To Erase All Programmed Codes

- Press and hold the green 'Smart Button' until the green indicator light turns off (approx 6 seconds). **All Codes are erased.**

CAD605 Instruction



Smart Button

- Press and **hold** the **B** button on the remote
 - Press and release the Green 'Smart button'
 - Release the B Code button
- The transmitter has been programmed into the opener

To Erase All Programmed Codes

- Press and hold the green 'Smart Button' until the green indicator light turns off (approx 6 seconds). **All Codes are erased.**