



Procedure if you have an existing remote

1. Open the new remote by removing the two screws at the rear.
2. Open your existing remote battery cover to expose the dip switches. [If you do not have an existing remote, please read procedure in blue text below.](#)
3. Match nine DIP switch positions (up or down) with your old remote.
4. Test new remote if works.

Trouble shooting: if doesn't work, please toggle every single DIP switch up and down a few times to make good contact of the tiny switch,

Procedure if you don't have an existing remote

1. Open case of new remote by undo two tiny screws at the back of the remote.
2. Set the switches to a random sequence.
3. Press and release the Code Set button on your wall control panel. A light will illuminate.
4. Press the button on new remote. The Code Set light will go out
5. Press the button on the new remote see if works to ensure you have programmed it correct.