

HOW TO PROGRAMME **Steel-line** ST50EVOB/C To Code Additional Handsets:



- Press and hold the button ① on the handset you would like to code to the unit.
- Locate the “S” button ② inside the light cover ④.
- Press and release the “S” button ② on the unit.
- The LED light ③ on the unit will flash to confirm learning of the handset.
- Release the button ① on the handset.