## **AUSSIE OPENERS**

## PROGRAMMING NEW REMOTE TO SECTIONAL DOOR OPENER

- 1. Press once and immediately release the code button on PDS 101 opener and Su should indicate on the screen.
- 2. Press any button on the remote twice that you would like to program to the door.

The Su on the motor should be flashing and then display - -

3. Now test the remote if works.

## PROGRAMMING NEW REMOTE TO ROLLER DOOR OPENER

- 1. Press once code button on the motor and immediately let go. A red dot LED light will illuminate.
- 2. Press twice any button on the remote which you want to use. The dot light should be flashing then off.
- 3. Now test the remote if works

magickey.com.au