

How to program Aussie 2B remote control

Press CODE button on drive unit in garage one second.

Press button **A** on new remote **Aussie 2B** one second

Press button **B** on new remote **Aussie 2B** one second.

Thats all. Now you can by turns to press button A and button B to operate your Aussie opener.

