

# AVANTI –3B remote instruction

## REMOTE

The 433MHz code hopping remote provides state of the art security by providing up to 1.2 billion possible code combinations. A new digital code is generated each time the button is pressed thereby ensuring the total security of your garage and its contents from potential coded scanning devices.

Up to 12 individual Hand Transmitter codes may be stored.

## CODE LEARNING

Remotes may be coded as follows;

- i. If needed hinge the Courtesy Lamp Cover open to expose the "Learn or Code Set Button otherwise it is on the rear of the motor head.
- ii. Decide which button of the new remote will control the opener
- iii. Momentarily press the "Learn or Code Set Button (\* LED Indicator will glow solid)
- iv. Momentarily press the New Remote button you want to control the door - LED indicator will extinguish
- v. Momentarily press the same Remote button again - LED indicator will begin to flash rapidly, programming is complete once the LED Indicator ceases to flash
- vi. If required close the Courtesy Lamp Cover



## CODE DELETING

All Remote codes may be deleted as follows;

- i. If needed hinge the Courtesy Lamp Cover open to expose the "Learn or Code Set Button otherwise it is on the rear of the motor head.
- ii. Momentarily press the "Learn or Code Set" Button - LED indicator will glow solid
- iii. Press and hold the black "Run" Button - LED indicator will begin to flash rapidly
- iv. All Remote Codes will have been deleted once the LED Indicator ceases to flash
- v. If required close the Courtesy Lamp Cover