DOORHAN REMOTE PROGRAMMING

A. To add a remote control

- 1. Press and hold the «R», until «00» appears on the display. Release the button.
- 2. Press any button of new remote you like to use twice.
- 3. Repeat above operations for other remote controls (maximum quantity -20 pcs.).
- 4. All the remote controls will be added sequentially into the control block.
- 5. When the maximum quantity of remote controls is exceeded; three long beeps will sound.

B. If your existing remote still work , you can program for Doorhan remote controller remotely

- 1. To press and hold the button «2» of the programmed remote control.
- 2. Without releasing the pressed button «2», to press and hold the button «1» of the remote control.
- 3. Release the buttons pressed.
- 4. Press the remote control button already set up.
- 5. On the new remote control, select a button with the help of which you will control the operator's work, and pressit twice. A beep will sound.