

## Herculift Program Instruction



Thank you for purchasing our product. Please follow the steps to do the program.

1. LEARN button on Receiver once, the Signal LED will be on
2. Press one button of the transmitter (the one you want to control the door), Signal LED will be off
3. Press the same button of the remote again, LED will be flashing  
When the LED stops flashing, the coding sequence is complete.

### **Delete coding**

Press and hold LEARN button on the receiver for about 10 sec, all the coding are removed.

## Herculift Program Instruction



Thank you for purchasing our product. Please follow the steps to do the program.

1. Press LEARN button on Receiver once, the Signal LED will be on
2. Press one button of the transmitter (the one you want to control the door), Signal LED will be off
3. Press the same button of the remote again, LED will be flashing  
When the LED stops flashing, the coding sequence is complete.

### **Delete coding**

Press and hold LEARN button on the receiver for about 10