

## Elsema KEY301R replacement

1. Remove your original remotes battery cover to reveal 12 little switches
2. Unscrew the back of the new remote to reveal the same 12 switches
3. Change the new remotes switches to match the old remote.
4. Put the cover back remotes and test if works.

Please note: New remote needs to press and hold a bit longer about 0.5 second time.

Please note: After copying the switches, if the remotes does not operate the door, please try the switches on the new remote in reverse (Position of switch 12 on the old remote will be the position of switch 1 on the new remote, position of switch 11 on the old remote will be the position of switch 2 on the new remote ect)

[www.mkey.com.au](http://www.mkey.com.au)