

MK302 Remote Coding Instructions

Set up your new 12-switch remote using your original 10-switch remote

Before you begin

The original remote has 10 DIP switches. The new MK302 remote has 12.

1

Open both remotes

Open the battery covers of the original remote and the new MK302 remote.

2

Copy switches 1-10

Set switches 1-10 on the new remote to exactly match the original remote.

3

Set switches 11 and 12

Move both switches 11 and 12 to the UP (ON) position.

4

Close and test

Replace the battery cover, then test the new remote.

New MK302 switch setting



IMPORTANT

Switches 1-10 must match the original remote exactly.

Switches 11 and 12 must both be UP (ON).