

How to Program Your Remote

Garage Door Opener Remote Programming Guide

Follow the steps below using the motor control panel on your garage door opener.

Before you start: Make sure you can safely access the motor control panel and that the remote battery is working.

Programming Steps

1	Press the CODE button Press and hold the CODE button on the motor control panel until the Coding LED turns on, then release the button.
2	Press the remote button Press and hold a button on your remote control for 2 seconds, then release it.
3	Press the same button again Press and hold the same button on the remote control again until the motor beeps and the Coding LED flashes.
4	Programming confirmed The remote has now been successfully programmed.
5	Test the remote Test the remote to make sure it opens and closes the garage door correctly.

When the motor beeps and the Coding LED flashes, the remote has been saved successfully.

IMPORTANT: Do not hold the CODE button down for too long. Holding the CODE button for too long may erase all remotes already programmed into the opener.

If the remote does not work

- Repeat the programming steps carefully.
- Check that the remote battery is working.
- Make sure you are pressing the same remote button in Steps 2 and 3.