MicroLatch instruction

- 1. Locate receiver box (Micro latch normally locates surround driver unit in garage)
- 2. Locate program button which is next red indicator on the receiver board.
- 3. Press the program button 1 second, red indicator will be blink
- 4. Press one button of new remote 1 second, the indicator still blinks. You can continue to program another remote if you have by press button of remote 1 second.
- 5. Press program button on receiver the indicator will be off. Now you can text the remote if works.