How to program 0&0 remote

1. locate the O&O receiver in gate control box or above the unit in garage.

You can find a PROG button on receiver card in the receiver.

2. Press the PROG button 1 second you can hear bee once

Press one button of new remote 1 second you can hear bee 2-3 times that means tuning successful.

3. wait 10 seconds you will hear two bees to confirm exit program.

Now you can test new remote if works.

