



### Adding extra transmitters of changing transmitters



Press **CODE**, it displays "Su", press a button on the transmitter, then release and press the same button again, "Su" flashes, then it displays "--" to show setting is complete.



Repeat previous steps to code a **maximum of 20** different transmitters' and/ or wall buttons.