

# PHOENIX Remote program

## **To program**

Press **CODE** button on the opener in garage once. press a button of new transmitter one second then release and press same button one second again. That's all.

Now you can test if works

## **To delete memories**

Press **CODE** button on the opener in garage once 10 seconds.