

Programming Instructions – Garage Motors

Press and release the S button located on the motor

The number zero will be displayed on the left hand side and will disappear immediately

Press the button twice on the new remote you wish to code to the door

Test the remote

Programming Instructions – Gate Motors

Press the code button located on the motor for 2 seconds and a light on the motor will illuminate

Press the button twice on the new remote you wish to code to the door

Test the remote