

Remote Control Programming Instruction

1. Locate the Learn/Code button on the motor and press this button once and immediately release
2. Press and hold any button on the new remote two times
3. Test the new remote

DELETING REMOTES

Press 'CODE' button more than 8 seconds until the LED displays 'C', all the stored codes will be deleted

www.magickey.com.au