

Programming procedure for DEA TR2 433Mhz rolling code key-fob transmitters

Please note that the TR2 is the replacement remote for the 273. The workings are the same but the casing looks totally different.

Method A (*requires an existing working DEA 273 or TR2 transmitter*)

1. Stand within 2 metres of your electric gate ariel, then take an existing working DEA transmitter and press the secret button which is located on the front of the transmitter, you will need something such as a paper clip to press the button as it is located in the very small hole on the front. You now have 10 seconds to perform the next step.
2. Take the new transmitter and press the button that you wish to use to operate your receiver for one second. Now wait 30 seconds for the receiver to exit programming mode.
3. Programming is now complete and your new handset should now operate your receiver.

Method B (*requires entry to the gate control box.*)

1. Locate the programming button inside your DEA gate control enclosure and press it briefly, an LED will light up on the receiver P.C.B., you now have 10 seconds to perform the next step.
2. Take the new transmitter and press the button that you wish to use to operate your receiver for one second. Now wait 30 seconds for the receiver to exit programming mode.
3. Programming is now complete and your new handset should now operate your receiver.